

THE ARROW HEAD AT THE END OF THE TRUSS ON THE TRUSS ON THE TRUSS PLACEMENT FLAN (LAYOUT)
CORRESPONDS WITH THE LEFT SIDE OF THE LOUTHDUAL TRUSS DRAWING, USE THIS AS AN ORIENTATION GUIDE WHEN SETTING THE FRUSSES ON THE FRUSSES ON THE TRUSSES ON THE TRUCTURE. 3

5

ieral Notes:

Per ANSI/TPI 1-2002 all "Truss to Wall" connections are the responsibility of the Building Designer, not the Truss Manufacturer's specifications for all hanger connections unless noted otherwise.

Trusses are to be 24" o.c. U.N.O.
All hangers are to be Simpson or equivalent U.N.O. Use 10d x 112" Nails in hanger connections to single ply prictor trusses.

irder trusses.

Trusses are not designed to support brick U.N.O.

Dimensions are Feet Inches Sixteenths

No back charges will be accepted by Builders FirstSource unless approved in writing first. 850-835-4541

ACQ lumber is corrisive to truss plates. Any ACQ lumb that comes in contact with truss plates (i.e. scabbed on tails) must have an approved barrier applied first.

Refer to BCSI-B1 Summary Sheet-Guide for handling, Installing and Bracing of Metal Plate Connected Wood Truss prior to and during truss installation.

It is the responsibility of the Contractor to ensure of the proper orientation of the truss placement plans as to the construction documents and field conditions of the structure orientation. If a reversed or flipped layout is required, it will be supplied at no extra cost by Builders

All common framed roof or floor systems must be designed as to NOT impose any loads on the floor trusses below. The floor trusses have not been designed to carry any additional loads from above. It is the responsibility of the Contractor to make sure the placement of trusses are adjusted for plumbing drops, can lights, eet.... so the trusses do not interfere with these type of items.

This truss placement plan was not created by an engineer, but rather by the Builders FiredSource staff and is solely to be used as an installation guide and does not require a seal. Complete truss engineering and analysis can be found on the truss design drawings which may be sealed by the truss design engineer.

Gable end trusses require continuous bottom chord bearing. Refer to local codes for wall framing

Although all attempts have been made to do so, trusses may not be designed symmetrically. Please refer to the individual truss drawings and truss placement plans for proper orientation and placement.

凹	
20	<u></u>
1	DESCRIPTION OF
	0
R	D
	S

Builder: G				
EIBEIG	Talla PHONE: 8	Jacks PHONE: 9 FAX: 90	Lak PHONE: 3 FAX: 380	FIR
GEIBEIG CONST.	Tallahassee PHONE: 850-576-5177	Jacksonville PHONE: 904-772-6100 FAX: 904-772-1973	Lake City PHONE: 386-755-6894 FAX: 386-755-7973	FIRSTSOURCE
	7	Ü	_	JRCE

Ploor 1 Job# N/A

1-31-21

KLH Floor 2 Job#: N/A

Original Ref#:
2623604
Roof Job #:

2623604

egal Address

LOT 18 WISE EST.