

#31432



JACKSONVILLE
4575 ST. AUGUSTINE ROAD
JACKSONVILLE, FL 32207
(904) 739-9883

Residential Termite Service
Master Agreement #: 53213-0145101
Work Order #: 12638005928

Customer Name: THOMAS WILLITS
Contact Name:
Customer #: 7750326
Sales Agrmt #: 13517126
Service Address: 259 SW MYSTIC WAY
FORT WHITE, FL 32038
Billing Address: 479 NW 345TH AVE
STEINHATCHEE, FL 32680

Home Phone: (904) 813-3428
Work Phone:
Cell Phone:
E-mail Address:
Frequency:
Last Svc Date:
Customer Since: 10/3/13

Service Technician: GAETANOS, PETER
Employee Number: 53213
License/Cert #:
Supervisor Name:
Supv.License/Cert #:
Service Type: Complete Treatment

Date/Time In: 10/03/2013 4 17PM
Date /Time Out: 10/03/2013 4 22PM
Page: 1

General Information:

Pretreatment
Structure Type Slab
Areas Inspected Inside & Outside
Linear Feet 118
Front Depth to Footer 1
Rear Depth to Footer 1
Left Depth to Footer 1
Right Depth to Footer 1
Date Posted 10/03/2013
Posted Notice Location Other

Activity

| | |
|-------------------|---|
| Activity Observed | o |
| Damage Observed | o |

Comments

Thank you for choosing Terminix. Your business is appreciated

Material Usage:

| Termidor SC .06% | | Areas Inspected/Treated | Pests Targeted | Post Treatment Precautions |
|--------------------------|---|--|--|---|
| Active Chemical : | FIPRONIL 0.06% | DETACHED GARAGE EXPANSION JOINT EXTERIOR AREAS FOUNDATION WALL As noted on graph | Subterranean Termites No Activity Noticed | Do not allow unprotected persons, children, pets to touch/replace items/bedding, to contact/enter treated areas til dry |
| EPA Reg #: | 7969-210 | | | |
| Treatment: | 117 See Attached Treatment Specs,172 See Attached Treatment Specs | | | |
| Applied Amount: | 84.000 Ounce | | | |
| Formulation: | Wettable Powder | | | |
| Equipment: | Truck Mounted Sprayer | | | |

Summary Of Charges:

| | | |
|------------------|--------|----------|
| Previous Balance | \$0.00 | |
| Current Charges | 450.00 | |
| SubTotal: | | \$450.00 |
| Tax: | | \$0.00 |
| Total: | | \$450.00 |



JACKSONVILLE
4575 ST. AUGUSTINE ROAD
JACKSONVILLE, FL 32207
(904) 739-9883

Residential Termite Service
Master Agreement #: 53213-0145101
Work Order #: 12638005928

Customer Name:

Customer Signature: Unavailable

Date:

Service Technician: PETER GAETANOS

**Service Technician
Signature:**

Date: 10/3/2013

Customer payments can be made either at www.terminix.com or by mailing payments to: Terminix Processing Center, PO Box 742592, Cincinnati, OH 45274-2592. Please include your customer number, noted above. Call 1-800-TERMINIX with questions or to find out about our Easy Pay options.

GENERAL TREATMENT SPECIFICATIONS

- 117 - Trench or trench and rod soil adjacent to the exterior foundation walls
- 117A - Vertically drill exterior attached slabs and treat soil beneath along point of attachment
- 118 - Excavate soil beneath dirt-filled porch slab at point or points of attachment to the structure and treat soil beneath
- 120 - Vertically drill the dirt-filled porch slab and treat the soil beneath the slab along the point or points of attachment to the structure
- 121A - Drill the exterior foundation wall of a crawl space or basement from the inside and treat the soil immediately beneath the dirt-filled porch slab by short-rodging along the point or points of attachment to the structure
- 121B - Drill through each side of the dirt-filled porch foundation wall at no greater than 12" intervals and treat the soil immediately beneath the dirt-filled porch slab by short-rodging along the entire inside perimeter of the DFP
- 121C - Drill foundation walls of the dirt-filled porch and treat the soil immediately beneath the slab by long-rodging adjacent to the entire inside perimeter of the DFP
- 128 - Trench, remove, and treat soil by the Backfill Method (see label)
- 129 - Drill and treat voids of a double brick foundation wall at 12" intervals or less
- 130 - Drill and treat voids of a stone foundation wall at 12" intervals or less
- 131 - Drill and treat voids of a triple brick foundation wall at 12" intervals or less
- 132 - Drill and treat voids of a hollow block foundation wall at 12" intervals or less
- 133 - Drill and treat voids of a brick veneer foundation wall at 12" intervals or less
- 134 - Drill and treat all voids of a chimney at 12" intervals or less
- 138 - Drill and treat a subterranean termite infested wooden sill or plate
- 140 - Drill and treat a subterranean termite infested wooden joist/s
- 145 - Drill into voids of termite infested wood and inject product into inaccessible voids, termite galleries and nests
- 146 - Make small openings into termite shelter tubes and inject product inside
- 147 - Make multiple openings into carton nests in building voids or in trees and make multiple injections of product to varying depths
- 160 - Trench, trench and rod, or rod soil of planter box adjacent to the exterior foundation wall according to state specific treatment standards or to label directions, whichever apply

CRAWL SPACE TREATMENT SPECIFICATIONS

- 114 - Trench or trench and rod soil adjacent to the inside of the foundation walls of a crawl space
- 115 - Trench or trench and rod soil adjacent to the piers of a crawl space
- 116 - Trench or trench and rod soil adjacent to soil pipes of a crawl space
- 119 - Trench or trench and rod soil adjacent to a chimney of a crawl space

SLAB TREATMENT SPECIFICATIONS

- 122A - Drill the slab at 12" intervals or less along the expansion joint where two slabs meet and treat soil underneath
- 123 - Treat soil adjacent to plumbing penetrations
- 123A - Drill the slab along one side of the partition wall at 12" intervals or less and treat the soil beneath
- 123AA - Drill the slab along both sides of a load-bearing wall at 12" intervals or less and treat the soil beneath
- 124 - Drill through the exterior foundation wall immediately below the slab at 12" intervals or less and treat the soil beneath by short-rodging from the outside
- 126 - Vertically drill the slab along the inside perimeter of the foundation walls and treat the soil beneath the slab

BASEMENT TREATMENT SPECIFICATIONS

- 122 - Vertically drill basement concrete slab floor and treat the soil beneath
- 144 - Drill and treat basement door frames

NON-CHEMICAL TREATMENT SPECIFICATIONS

- 101 - Provide at least 14" clearance between wood and soil in the crawl space
- 102 - Install access to ceiling of basement for inspection and/or treatment
- 104 - Install door/s to provide access for treating soil adjacent to plumbing
- 105 - Install crawl space access door
- 106 - Install Automatic Vents
- 109 - Remove cellulose debris and/or any other debris that would interfere with inspection or treatment in the crawl space
- 109A - Remove form boards
- 110 - Scrape off termite tunnels
- 111 - Set wooden supports on concrete pads to properly insulate wood to soil contact
- 135 - Cut off stucco at least 3" above grade and remove stucco below grade
- 149 - Remove wood to ground contacts
- 152 - Break ground contact on step stringers
- 161 - Prepare floor surface for drilling, ____ Tile ____ Wood Floor ____ Carpet ____ Terrazzo
- 205 - Install a vapor barrier over the soil of a crawl space
- 206 - Install floor supports to provide additional support

PRE-CONSTRUCTION TREATMENT SPECIFICATIONS

- 170 - Vertical treatment zone - trench or trench and rod soil adjacent to the inside of the exterior foundation walls
- 171 - Vertical treatment zone - trench or trench and rod soil adjacent to pillars and other interior foundation elements such as chimneys and soil pipes
- 172 - Vertical treatment zone - trench or trench and rod soil adjacent to utility pipes, plumbing lines, and conduits that will penetrate through the slab (1 gallon/sq.ft.)
- 173 - Horizontal treatment zone - make a horizontal treatment to the entire surface area of soil or substrate to be covered beneath the concrete slab
- 174 - Vertical treatment zone - Upon completion of grading along the outside of the exterior foundation wall, treat the backfill by trenching or trenching and rodding the soil adjacent to the exterior foundation wall



JACKSONVILLE
4575 ST. AUGUSTINE ROAD
JACKSONVILLE, FL 32207
(904) 739-9883

Residential Termite Service
Master Agreement #: 53213-0144169
Work Order #: 12600351149

Customer Name: THOMAS WILLITS
Contact Name:
Customer #: 7750326
Sales Agrmt #: 13475769
Service Address: 259 SW MYSTIC WAY
FORT WHITE, FL 32038
Billing Address: 479 NW 345TH AVE
STEINHATCHEE, FL 32680

Home Phone:
Work Phone:
Cell Phone:
E-mail Address:
Frequency:
Last Svc Date:
Customer Since:

Service Technician: GAETANOS, PETER
Employee Number: 53213
License/Cert #:
Supervisor Name:
Supv. License/Cert #:
Service Type: Complete Treatment

Date/Time In: 09/26/2013 8:49AM
Date /Time Out: 09/27/2013 9 59AM
Page: 1

General Information:

Original Treatment
Structure Type Slab
Areas Inspected Inside & Outside
Linear Feet 180
Front Depth to Footer 1
Rear Depth to Footer 1
Left Depth to Footer 1
Right Depth to Footer 1
Date Posted 09/27/2013
Posted Notice Location Other

Activity

| | |
|-------------------|---|
| Activity Observed | o |
| Damage Observed | o |

Comments

Thank you for choosing Terminix Your business is appreciated

Material Usage:

| Termidor SC .06% | | Areas Inspected/Treated | Pests Targeted | Post Treatment Precautions |
|--------------------------|--|-------------------------|--|--|
| Active Chemical : | FIPRONIL 0.06% | EXPANSION JOINT | Drywood Termites - No Activity Noticed | Do not allow unprotected persons, children, pets to touch/replace items/bedding, to contact/enter treated areas till dry |
| EPA Reg #: | 7969-210 | EXTERIOR AREAS | | |
| Treatment: | 117 - See Attached Treatment Specs, 171 - See Attached Treatment Specs | FOUNDATION WALL | | |
| Applied Amount: | 200.000 Gallon | PIERS | | |
| Formulation: | Wettable Powder | SLAB - EXTERIOR | | |
| Equipment: | Truck Mounted Sprayer | SLAB INTERIOR | | |
| | | As noted on graph | | |


Summary Of Charges:

| | | |
|------------------|--------|----------|
| Previous Balance | \$0.00 | |
| Current Charges | 945.00 | |
| SubTotal: | | \$945.00 |
| Tax: | | \$0.00 |
| Total: | | \$945.00 |



JACKSONVILLE
4575 ST. AUGUSTINE ROAD
JACKSONVILLE, FL 32207
(904) 739-9883

Residential Termite Service
Master Agreement #: 53213-0144169
Work Order #: 12600351149

| | | | | | |
|----------------------------|----------------------------|--------------------------------------|---|--------------|-----------|
| Customer Name: | Customer Signature: | Unavailable | Date: | | |
| Service Technician: | PETER GAETANOS | Service Technician Signature: |  | Date: | 9/27/2013 |

Customer payments can be made either at www.terminix.com or by mailing payments to: Terminix Processing Center, PO Box 742592, Cincinnati, OH 45274-2592. Please include your customer number, noted above. Call 1-800-TERMINIX with questions or to find out about our Easy Pay options.

GENERAL TREATMENT SPECIFICATIONS

- 117 - Trench or trench and rod soil adjacent to the exterior foundation walls
- 117A – Vertically drill exterior attached slabs and treat soil beneath along point of attachment
- 118 – Excavate soil beneath dirt-filled porch slab at point or points of attachment to the structure and treat soil beneath
- 120 – Vertically drill the dirt-filled porch slab and treat the soil beneath the slab along the point or points of attachment to the structure
- 121A – Drill the exterior foundation wall of a crawl space or basement from the inside and treat the soil immediately beneath the dirt-filled porch slab by short-rod drilling along the point or points of attachment to the structure
- 121B – Drill through each side of the dirt-filled porch foundation wall at no greater than 12" intervals and treat the soil immediately beneath the dirt-filled porch slab by short-rod drilling along the entire inside perimeter of the DFP
- 121C – Drill foundation walls of the dirt-filled porch and treat the soil immediately beneath the slab by long-rod drilling adjacent to the entire inside perimeter of the DFP
- 128 – Trench, remove, and treat soil by the Backfill Method (see label)
- 129 – Drill and treat voids of a double brick foundation wall at 12" intervals or less
- 130 – Drill and treat voids of a stone foundation wall at 12" intervals or less
- 131 – Drill and treat voids of a triple brick foundation wall at 12" intervals or less
- 132 – Drill and treat voids of a hollow block foundation wall at 12" intervals or less
- 133 – Drill and treat voids of a brick veneer foundation wall at 12" intervals or less
- 134 – Drill and treat all voids of a chimney at 12" intervals or less
- 138 – Drill and treat a subterranean termite infested wooden sill or plate
- 140 – Drill and treat a subterranean termite infested wooden joist/s
- 145 – Drill into voids of termite infested wood and inject product into inaccessible voids, termite galleries and nests
- 146 – Make small openings into termite shelter tubes and inject product inside
- 147 – Make multiple openings into carton nests in building voids or in trees and make multiple injections of product to varying depths
- 160 – Trench, trench and rod, or rod soil of planter box adjacent to the exterior foundation wall according to state specific treatment standards or to label directions, whichever apply

CRAWL SPACE TREATMENT SPECIFICATIONS

- 114 – Trench or trench and rod soil adjacent to the inside of the foundation walls of a crawl space
- 115 – Trench or trench and rod soil adjacent to the piers of a crawl space
- 116 – Trench or trench and rod soil adjacent to soil pipes of a crawl space
- 119 – Trench or trench and rod soil adjacent to a chimney of a crawl space

SLAB TREATMENT SPECIFICATIONS

- 122A – Drill the slab at 12" intervals or less along the expansion joint where two slabs meet and treat soil underneath
- 123 – Treat soil adjacent to plumbing penetrations
- 123A – Drill the slab along one side of the partition wall at 12" intervals or less and treat the soil beneath
- 123AA – Drill the slab along both sides of a load-bearing wall at 12" intervals or less and treat the soil beneath
- 124 – Drill through the exterior foundation wall immediately below the slab at 12" intervals or less and treat the soil beneath by short-rod drilling from the outside
- 126 – Vertically drill the slab along the inside perimeter of the foundation walls and treat the soil beneath the slab

BASEMENT TREATMENT SPECIFICATIONS

- 122 – Vertically drill basement concrete slab floor and treat the soil beneath
- 144 – Drill and treat basement door frames

NON-CHEMICAL TREATMENT SPECIFICATIONS

- 101 – Provide at least 14" clearance between wood and soil in the crawl space
- 102 – Install access to ceiling of basement for inspection and/or treatment
- 104 – Install door/s to provide access for treating soil adjacent to plumbing
- 105 – Install crawl space access door
- 106 – Install Automatic Vents
- 109 – Remove cellulose debris and/or any other debris that would interfere with inspection or treatment in the crawl space
- 109A – Remove form boards
- 110 – Scrape off termite tunnels
- 111 – Set wooden supports on concrete pads to properly insulate wood to soil contact
- 135 – Cut off stucco at least 3" above grade and remove stucco below grade
- 149 – Remove wood to ground contacts
- 152 – Break ground contact on step stringers
- 161 – Prepare floor surface for drilling: ____ Tile ____ Wood Floor ____ Carpet ____ Terrazzo
- 205 – Install a vapor barrier over the soil of a crawl space
- 206 – Install floor supports to provide additional support

PRE-CONSTRUCTION TREATMENT SPECIFICATIONS

- 170 - Vertical treatment zone – trench or trench and rod soil adjacent to the inside of the exterior foundation walls
- 171 – Vertical treatment zone – trench or trench and rod soil adjacent to pillars and other interior foundation elements such as chimneys and soil pipes
- 172 – Vertical treatment zone – trench or trench and rod soil adjacent to utility pipes, plumbing lines, and conduits that will penetrate through the slab (1 gallon/sq.ft.)
- 173 – Horizontal treatment zone – make a horizontal treatment to the entire surface area of soil or substrate to be covered beneath the concrete slab
- 174 – Vertical treatment zone – Upon completion of grading along the outside of the exterior foundation wall, treat the backfill by trenching or trenching and rod drilling the soil adjacent to the exterior foundation wall