

THE ARROW HEAD AT THE END OF THE TRUSS ON THE TRUSS PLACEMENT CORRESPONDS WITH THE LEFT SIDE OF THE INDIVIDUAL TRUSS DRAWING, USE THIS AS AN DRIENTATION GUIDE WHEN SETTING THE TRUSSES ON THE STRUCTURE.

eneral Notes

· Per ANSI/TPI 1-2002 all " Truss to Well" connection re the responsibility of the Building Designer, not the 'russ Manufacturer.

- Use Manufacturer's specifications for all hanger connections unless noted otherwise.
 Trusses are to be 24" o.c. U.N.O.
- All hangers are to be Simpson or equivalent U.N.O.-Use 10d x 1 1/2" Nails in hanger connections to single ply girder trusses.

 Trusses are not designed to support brick U.N.O.

 Dimensions are Feet-Inches Sixteenths

No back charges will be accepted by Builders FirstSource ut 850-835-4541 ce unless approved in writing first.

ACQ lumber is corrisive to truss plates. Any ACQ lumber that comes in contact with truss plates (i.e. scabbed on tails) must have an approved barrier applied first.

Refer to BCSI-B1 Summary Sheet-Guide for handling, Installing and Bracing of Metal Plate Connected Wood Truss prior to and during truss installation.

It is the responsibility of the Contractor to ensure of the proper orientation of the truss placement plaus as to the construction documents and field conditions of the structure orientation. If a reversed or flipped layout is required, it will be supplied at no extra cost by Builders

It is the responsibility of the Contractor to make sure the placement of trusses are adjusted for plumbing drops, can lights, ect..., so the crusses do not interfere with these

All common framed roof or floor systems must be designed as to NOT impose any loads on the floor trusces below. The floor trusses have not been designed to carry any additional loads from above.

This truss placement plan was not created by an engineer, but rather by the Builders FirstSource staff and is solely to be used as an installation guide and does not require a seal. Complete truss engineering and analysis can be found on the truss design drawings which may be sealed by the truss design engineer.

Gable end trusses require continuous bottom chord bearing. Refer to local codes for wall framing

Although all attempts have been made to do so, trusses may not be designed symmetrically. Please refer to the individual truss drawings and truss placement plans for proper orientation and placement.



Lake City PHONE: 386-755-6894 FAX: 386-755-7973

Jacksonville PHONE: 904-772-6100 FAX: 904-772-1973

Tallahassee PHONE: 850-576-5177

GEIBEIG CONST.

Lot 29 Crosswinds

Date:	Drawn By:	Original Ref#:
7-27-22	KLH	3250262
Floor 1 Job#	Floor 2 Job#:	tteof Job #:
N/A	N/A	3250262