

SYMBOL:  For Nailing: See Simpson Catalog
QTY: 12 or Call 1-800-999-5099
SIMPSON HUS26






ROOF
TRUSS
LAYOUT

SCALE:
1/8" = 1'-0"

SOUTHRUST CONSTRUCTION
ADAMS RESIDENCE

Ridgway Roof Truss Company
235 SW 11th Place Gainesville, Florida 32601
Telephone (352) 376-4436 FAX (352) 371-3316
E-Mail: Sales@RidgwayTruss.com

REV.	BY	CHK.	DATE	REVISION
00				
01				
02				
03				
04				
05				
06				
07				
08				
09				
10				
11				
12				
13				
14				
15				
16				
17				
18				
19				
20				
21				
22				
23				
24				
25				
26				
27				
28				
29				
30				
31				
32				
33				
34				
35				
36				
37				
38				
39				
40				
41				
42				
43				
44				
45				
46				
47				
48				
49				
50				
51				
52				
53				
54				
55				
56				
57				
58				
59				
60				
61				
62				
63				
64				
65				
66				
67				
68				
69				
70				
71				
72				
73				
74				
75				
76				
77				
78				
79				
80				
81				
82				
83				
84				
85				
86				
87				
88				
89				
90				
91				
92				
93				
94				
95				
96				
97				
98				
99				
100				



LEGEND	
	SUPPLIED BEAM
	BEAM BY OTHERS
	VALLEY / FIELD FRAMING
	PLUMBING DROP
	SLOPED CEILING
	RAISED FLAT CEILING
	9'-1 1/8" BEARING HEIGHT
	10'-1 1/8" BEARING HEIGHT

"DISCLAIMER"

PLUMBING / HVAC OPENINGS ARE THE RESPONSIBILITY OF THE CONTRACTOR OR OWNER TO VERIFY ALL LOCATIONS BEFORE BUILDING TRUSSES AND SETTING TRUSSES.

"ATTENTION"

1. LIMITED RESPONSIBILITY OF ROOF TRUSS MANUFACTURER, SEE WTC 1-1-1995, SECTION 6.0, FOUND IN DESIGN MANUAL.

2. WARNING FAILURE TO FOLLOW RECOMMENDATIONS IN "BCSI" MAY RESULT IN SERIOUS INJURY, LOSS OF LIFE, OR PROPERTY DAMAGE.

SEE: WWW.BCINDUSTRY.COM/DOCS/06_BCSI_BOOKLET_FINAL.PDF

3. STRUCTURAL ENGINEER OF RECORD AND/OR THE ARCHITECT MUST CHECK ALL OF THE TRUSSES TO MAKE SURE THEY MEET THE STANDARD LOADING FOR THE BUILDING AND ANY OTHER SPECIAL LOADING CONDITIONS NEEDED.

4. CUSTOMER TO VERIFY ALL DIMENSIONS, BEARING HEIGHTS, PITCHES AND ALL INFORMATION REGARDING THE DESIGN AND FABRICATION OF TRUSS SYSTEM.

5. DO NOT OVERLOAD TRUSSES

6. TRUSSES ARE NOT MARKED IN ANY WAY TO IDENTIFY THE FREQUENCY, OR LOCATION OF TEMPORARY ERECTION BRACING. ALL TEMPORARY BRACING SHALL COMPLY WITH THE LATEST EDITION OF BCSI-B1 PUBLISHED BY THE TRUSS PLATE INSTITUTE FOUND IN THE DESIGN MANUAL.

7. NON-LOAD BEARING WALLS TO BE SINGLE TOP PLATED. TO PREVENT LOAD TRANSFER TO THESE WALLS A 1x4 MAY BE USED AS SECOND TOP PLATE

8. DO NOT CUT OR MODIFY ANY TRUSSES WITHOUT FIRST CONTACTING RIDGWAY ROOF TRUSSES FOR APPROVAL. ANY MODIFICATION TO THE TRUSSES WILL COMPROMISE THE STRUCTURAL INTEGRITY. ALL TRUSS MODIFICATION REQUESTS MUST BE SUBMITTED IN WRITING TO RIDGWAY ROOF TRUSSES PRIOR TO FIELD CHANGES.