

**⚠ CAUTION! ⚠**  
 All power must be shut off prior to wiring,  
 installation, or service.  
 More than one disconnect may be required to  
 de-energize this panel.



## SIGN LIGHT OVERRIDE

OUTSIDE LIGHT OVERRIDE

INCIDE LIGHTS OUTSIDE

### Verifying the Time and Date

From the  Home screen.

1. The Date is in the upper left corner of the Home screen.
2. The Time is in the upper right corner of the Home screen.

### HVAC Control Status

- \* Press the  Home screen button.
- \* Press the  arrow key.
- \* From the screen you can view:
  - i. Cld Temp (Control Temp - The sales floor temp).
  - ii. Values in [ ] represent the set point we are trying to maintain.
  - iii. Space Temp (Temperature at problem on Sales Floor).
  - iv. Supply Temp (Air Temp leaving AHU).
  - v. Status of Fan/Fan-Cools
- \* When complete, select the  Home button.

\* When complete, select the  Home button.

### Lighting Status

- \* The status of Store Lights can be viewed in the bottom left corner of the Home page, or by the following:
- \* Press the  Home screen button.
- \* Select F2 Lighting.
- \* Highlight the appropriate Lighting Control, then select enter.
- \* When complete, select the  Home button.

### Refrigerated Case Status

- \* Case Temperature can be viewed from the  Home screen.  
To view a graph of the case temperature:
  - i. Highlight the Temp value and select enter.
  - ii. Select F5 for graph.To zoom select F5 Zoom-In.  
(Press F5 Zoom-In as many times as necessary, get to the desired scale/range).  
(Use the left and right arrow keys to move to the time/date range desired).
- \* When complete, select the  Home button.

### Alarm Status

From the  Home screen, select  Alarm button.

1. **Time:** The time the alarm occurred.
2. **Date:** The date the alarm occurred.
3. **State:** Notice, Alarm or Fail.
  - \* Notices are general warnings that notify a user of minor errors.
  - \* Alarms are warnings about important system conditions that need immediate attention.
  - \* Fails are high priority conditions, warning the user of a controller or device failure.
4. **Property on Board and Point:** The item that has generated the alarm.
5. **Message:** The description of the notice, alarm or fail.
  - a. Using the up or down arrow keys, highlight the appropriate alarm and select the **Expand** button.
    - i. **Expand Info:** Expanded information will give the unit & detailed status of the alarm.
    - ii. When finished viewing detailed status, select enter.
6. **When complete, select the  Home button.**

**Escalation Contact List**

If you need HVAC Maintenance, call 866-300-0004, option 1.  
If you have Temperature Set Point concerns, contact your District Manager.  
If you are having problems with your Lights, call 866-300-0004, option 6.  
If you are having problems with your Coolers, call 866-300-0004, option 2.  
If you are having problems with your Sign, call 866-300-0004, option 1.  
If your store hours change, call 866-300-0004, option 6.



# DOLLAR GENERAL®

LAKE CITY, FLORIDA  
COUNTY RD 247, LAKE CITY, FL

STORE # 12851

2010 PROTOTYPE - PLAN "C" 9,100

|           |              |
|-----------|--------------|
| DATE      | 30 MAR 2010  |
| Design    | JFB 06/10/10 |
| Revisions | JFB 10/20/10 |

SHEET NUMBER

# EMS3.C

**NE**

**NICHOLAS  
GEISLER  
ARCHITECT**

1758 N. Lake  
Circle  
386/7750

**GC**

**CASCO**

10877 WATSON ROAD  
DUBLIN, OH 43017  
PHONE: 314-821-1100

DATE: \_\_\_\_\_

COM: \_\_\_\_\_

DATE:

COMM:

AR0007005