
Z

PROJECT NO. 22.R028

-SIMPSON H2.5T 5-8d NAILS TO TRUSS 5-8d NAILS TO HEADER 1x furring -@ 16" o.c. -dbl 2x12 header w/ 1/2 spacer vinyl soffit unless otherwise noted simpson LSTA24 18-10d nails (2) required -wrap header with aluminum coil stock P.T. 4x4 POST


PORCH SECTION


SCALE: 3/4" = 1'-0"




TOP PLATE SPLICE DETAILS

SCALE: 1/2" = 1'-0"







CORNER POST/HEADER DETAIL




INTERMEDIATE POST (OPTION 2)





SOFFIT/DROPPED CLG.

CORNER POST (front porch option)




PENETRATIONS


FIREBLOCKING NOTES:

FIREBLOCKING SHALL BE INSTALLED IN WOOD FRAME CONSTRUCTION IN THE FOLLOWING LOCATIONS:

- 1. IN CONCEALED SPACES OF STUD WALLS AND PARTITIONS INCLUDING FURRED SPACES AT CEILING AND FLOOR LEVELS.
- 2. AT ALL INTERCONNECTIONS BETWEEN CONCEALED VERTICAL AND HORIZONTAL SPACES SUCH AS OCCUR AT SOFFITS, DROP CEILINGS, COVE CEILINGS, ETC.
- 3. IN CONCEALED SPACES BETWEEN STAIR STRINGERS AT THE TOP AND BOTTOM OF
- 4. AT OPENINGS AROUND VENTS, PIPES, DUCTS, CHIMNEYS AND FIREPLACES AT CEILING AND FLOOR LEVELS WITH PYROPANEL MULTIFLEX SEALANT
- 5. AT ALL INTERCONNECTIONS BETWEEN CONCEALED VERTICAL STUD WALL OR PARTITION SPACES AND CONCEALED SPACES CREATED BY AN ASSEMBLY OF FLOOR JOISTS, FIREBLOCKING SHALL BE PROVIDED FOR THE FULL DEPTH OF THE JOISTS AT THE ENDS AND OVER THE SUPPORTS.



TYPICAL WALL SECTION SCALE: 3/4" = 1'-0"



24" o.c. horizontally and 16" o.c. vertically

BRICK FLASHING
SCALE: 1 1/2" = 1'-0"