



Supplemental Instructions

Pan Doors: Residential



reinforcement. Higher wind pressures and larger doors require additional

application. Premature failure of door system may result from improper

approved wind pressures and door sizes. See chart in lower left corner of drawing sheet one for the



installation steps and related safety information. These supplemental instructions do not contain basic door


information may result in injury or death. Failure to follow basic installation steps and related safety

basic door installation steps and related safety information. Door installers must follow a primary instruction manual for

any building code. Local building code officials determine compliance criteria. building code directives is the responsibility of the building owner/designer. Use of a reinforced garage door does not constitute automatic compliance with The correct selection of door and framing materials in adherence with local

A locking system must be installed if the door is not electrically operated

See drawing for stop molding requirements, when door is not more than 1" wider than opening When using stop molding, secure molding with minimum 8d nails or 2-1/2" long screws



Date: 2021.09.27 11:30:45 -05'00' Digitally signed by John E Scates

Supplemental_Instructions_Pan

Copyright 2020 C.H.I. Overhead Doors

and the signature must be verified on any electronic copies

2560 King Arthur, Ste 124-54 Lewisville, Texas 75056 TXPE 56308, F-2203 Florida P.E. # 51737

John E. Scates, P.E

Professional Engineer's seal provided only for verification of windload construction details

For Use With Drawing Number Z3-10-01307

Strut Placement

1	2	3	4	5	6	7	8	9	10	11	12	Section Number	
1 at Detail B	0	0	1 at Detail A	N/A	6'-6" to 7'-0"								
1 at Detail B	0	0	1 at Detail A	1 at Detail A	N/A	7'-6" to 8'-0"							
1 at Detail B	0	0	1 at Detail A	1 at Detail A	N/A	8'-3" to 8'-9"							
1 at Detail B	0	0	1 at Detail A	0	1 at Detail A	N/A	N/A	N/A	N/A	N/A	N/A	9'-0" to 10'-6"	
1 at Detail B	0	0	1 at Detail A	0	0	1 at Detail A	N/A	N/A	N/A	N/A	N/A	10'-9" to 12'-3"	Door l
1 at Detail B	0	0	1 at Detail A	1 at Detail A	0	0	1 at Detail A	N/A	N/A	N/A	N/A	12'-6" to 14'-0"	Door Height
1 at Detail B	0	0	1 at Detail A	0	1 at Detail A	0	0	1 at Detail A	N/A	N/A	N/A	14'-3" to 15'-9"	
1 at Detail B	0	0	1 at Detail A	0	0	1 at Detail A	0	0	1 at Detail A	N/A	N/A	16'-0" to 17'-6"	
1 at Detail B	0	0	1 at Detail A	1 at Detail A	0	0	1 at Detail A	0	0	1 at Detail A	N/A	17'-9" to 19'-3"	
1 at Detail B	0	0	1 at Detail A	0	1 at Detail A	0	0	1 at Detail A	0	0	1 at Detail A	19'-6" to 20'-0"	

Push Nut Detail (use on all rollers)

use 3/8" I. D. on bottom fixture roller stem use 7/16" I. D. on end hinge and top fixture roller stems





Track Bracket Spacing

Track bracket spacing shown for doors up to four sections high. Additional door sections may be added for maximum door height depicted on line drawing. Track brackets must be added (per track) for each section and spaced at a distance not greater than the corresponding section height (see line drawing for required quantities).

Strut Placement Concerning Windows

Where a strut crosses a window, it is acceptable to move the strut from a position of "Strut above hinge" down to "Strut on top half of the hinge".





For Use With Drawing Number

Z3-10-01307

Strut Placement Detail

